



Sony Ericsson W580i SIM Card Replacement

How to remove the SIM card.

Written By: Diego



INTRODUCTION

Use this guide to remove or replace your SIM card.



TOOLS:

- [Spudger](#) (1)
-

Step 1 — Battery



- Hold the phone with the screen facing down. Push the back cover firmly down and slide it towards you.
- The panel will slide down about 2mm.
- Lift the panel away from the phone.

Step 2



- Lift the battery out from the bottom edge.

Step 3 — SIM Card



- Locate the SIM card slot.
- Use a spudger to release the SIM card by pushing it in slightly until you feel a "click."
- Release pressure from the SIM card. The SIM card will pop out about 5mm.

Step 4



- Slide the SIM card down out of the slot.
- Remove the SIM card from the phone.

To reassemble your device, follow these instructions in reverse order.

